




# Uninstalling the Device Driver

1. 「Control Panel」 → 「Uninstall a Program」 → 「PL-2303 Driver Installer」






2. The InstallShield Wizard will appear and prompt you if you want to completely remove the driver, click Yes to continue.
3. When finished, the InstallShield Wizard will prompt you that uninstall is complete, click Finish to continue. You need to restart Vista after uninstall procedure.




# Installation PL-2303 Driver for Vista PC system

Windows Vista only need install “PL-2303 Vista Driver Installer.exe”

1. Double click “PL-2303 Vista Driver Installer.exe”




2. Click “Next”



3. Accept the terms of the license agreement and click “Next”



4. Click “Finish” to complete setup program



5. Complete the installation connecting the devices, there will be a pop-up message, please follow the indications.

